

LABORATORY WASTE MANAGEMENT

Presented by the:
Environmental Health
and Safety Office





Laboratory and Studio Waste Management



WASTE MANAGEMENT GUIDE

September 2011 version

Environmental Health and Safety Office Ball State University





BSU Laboratory Waste Management Plan



Prepared by the:

Environmental Health and Safety Office North Service Building 3401 North Tillotson Avenue Muncie, Indiana 47306 765-285-2807 or tlrussell@bsu.edu

August 2013



U.S. Environmental Protection Agency (EPA): Definition of Laboratory

Laboratory means an area owned by an eligible academic entity where relatively small quantities of chemicals and other substances are used on a non-production basis for teaching or research (or diagnostic purposes at a teaching hospital) and are stored and used in containers that are easily manipulated by one person. Photo laboratories, art studios, and field laboratories are considered laboratories. Areas such as chemical stockrooms and preparatory laboratories that provide a support function to teaching or research laboratories (or diagnostic laboratories at teaching hospitals) are also considered laboratories.

Note: This waste management procedure applies only to laboratories, as defined above—not other shops, custodial, or maintenance activities on campus.



Waste Separation

Clearly label all wastes!

Wastes should be separated by type:

Lab (Studio) Wastes:

- Hazardous chemical wastes; or,
- Non-hazardous chemical wastes

Other Wastes:

- Autoclave Wastes
- Biohazard Wastes
- Sharps
- Broken Glass
- Special Wastes
- Drain Disposal
- General refuse









Autoclave Wastes

Clearly label all wastes!

Commonly autoclaved wastes include:

- Disposable lab ware, except Pasteur pipettes, contaminated with potentially infectious (blood, body fluids, human cell culture media, bacteria culture media, viruses, recombinant DNA, etc.);
- Gloves, regardless of contaminated or not, and paper towels used for work surface or equipment decontamination must be disposed of in a clear autoclave bag or red biohazard bag;
- Pasteur pipettes should be disposed of in sharps container.;
- Culture plates;
- Culture media;
- Animal cages and bedding from infected animals

Biohazard wastes nor autoclaved should be placed in infectious waste bags/boxes or sharps containers.







Biohazardous Wastes

- Unless to be autoclaved or chemically disinfected, all potentially infectious materials should be placed in an infectious waste container or bag
- Do not overfill the container or use for normal trash disposal;
- Do not push down on the container contents with your hands or feet.
- These wastes are routinely picked up for offsite treatment and disposal by an approved vendor.









Biohazard Box and 5 Gallon Biohazard Pail



Sharps

Clearly label all wastes!

Sharps

- All sharps, including those not potentially infective or contaminated, should be put into a proper sharps container.
- Do not fill the container more than ³/₄ full;
- Do not attempt to open a closed container;
- Contact the EHS Office if any injuries;
- Contact the EHS Office for removal.





Broken Glass

Clearly label all wastes!

- All broken glass or other (non-infectious) sharp materials should be placed in a *Broken Glass* container
- If none are available—the broken glass should be placed in a fiber box, pail, or other protective container and labeled as "Broken Glass" and set next to, or in, a refuse container.
- Do not attempt to pick up broken glass with bare hands use leather gloves, a broom and dustpan, tongs, or other devices.







General Refuse



- Do not put the afore-mentioned materials into regular refuse containers (in-room waste cans or dumpsters)
- Do not put liquid wastes into the waste cans unless contained add absorbents (kitty litter, oil dry) if necessary.
- Do not put heavy items or objects with sharp edges that may tear the container liners or injure custodians into trash receptacles.
- Contact building maintenance (custodial) for any problems with regular trash pickup from building interiors (through BSU work control 55081





Do not dispose of waste chemicals or free liquids in trash containers!



Special Wastes





Aerosol Cans

- Discharge completely to atmospheric pressure (no propellant) then scrap
- Gas Cylinders (propane, lecture bottles, small cylinders)
 - Discharge completely (no contents or propellant) can then go as scrap metal

Oily Rags or Solvent Wipes

- Place in oily rag containers
- Do not leave on the floor or exposed to air
- Should be emptied every night

Used Oil

- linseed oil handle as a hazardous waste (flammable)
- other oils (petoleum, vegetable, vacuum pump, synthetic) label as USED OIL, not "waste" oil should be collected for recycling
- Do <u>not</u> mix used oil with other liquid wastes, particularly solvents







Drain Disposal



- Refer to the Disposal of Laboratory Wastes: Requirements for Chemical Disposal to Sinks and Drains document (available on the EHS Office website) for information on, and a listing of, those liquid wastes that may be approved for disposal to laboratory drains.
- Generally, the following materials are suitable for drain disposal:
 - They are liquids and readily water soluble (at least 3% soluble);
 - Easily biodegradable or amenable to treatment by the waste water treatment process;
 - Are simple salt solutions of low toxicity inorganic substances;
 - Are dilute organic substances of low aquatic toxicity and low concentration; and,
 - Have a pH between 5.5 and 9.5
 - There are, however, many wastes, including fats, oils, and grease, toxic substances, reactives, non-water soluble materials, and many others, that may not be disposed to the sewerage system. The above-referenced document should be reviewed before such disposal, or the EHS Office and Muncie Bureau of Water Quality must be contacted for prior assessment and approval.



General Chemical Waste Handling

- Place waste in a proper, closable container.
 - Original or shipping container is usually fine.
 - Use larger or 5-gallon carboys, if practical.
 - Use safety cans if flammable wastes
- Label the container contents and any hazards!
- No containers that are, or look like, beverage bottles or food containers!
- Keep containers closed. NO OPEN FUNNELS.
- Keep the waste in your studio/lab/workshop where it is generated.
- Secondary containment is needed if liquids near floor drains or sink drains.








What is Hazardous Waste?



Resource Conservation & Recovery Act (RCRA)



- Enacted in 1976 by EPA as an amendment to the Solid Waste Disposal Act (SWDA)
- Main objectives:
 - Protect human health & the environment
 - conserve valuable material & energy resources
- Established "Cradle-to-grave" management and tracking of hazardous waste
- EPA inspectors have same authority as FBI/ATF - Violations serious
- Misidentification of wastes often leads to subsequent handling/disposal violations





HAZARDOUS Wastes







Hazardous wastes are regulated because they present special hazards to man or to the environment if they are improperly disposed of or discarded.

The hazardous waste (RCRA) regulations are very stringent due to past chemical waste disposal abuses.

The difference between a *hazardous* waste and a *nonhazardous* chemical waste can be very small – due to a physical characteristic of the waste, concentration of a constituent, the particular chemicals in the waste, or the process that generated the waste..





So... is <u>your</u> waste a hazardous waste?




You Might Have A Hazardous Waste If



The Compound Or Solution meets a Characteristic of Hazardous Waste:

- Ignitable
- Corrosive
- Reactive
- Toxic



Or, if it is "Listed" as a Hazardous Waste.

F	K	P	U
Non-specific Source wastes	Source- specific wastes	Acutely hazardous wastes	Toxic wastes





Hazardous Waste: Exception

UNIVERSAL WASTE
SHIPPERADDRESSCITY, STATE, ZIP
CONTENTS

■ Universal waste (batteries; lamps; mercury from thermometers) — These wastes have lesser requirements—if they are to be recycled. They must be labeled as "Universal Wastes" and be removed for recycling within one year of their accumulation or "removal from service".









Characteristic Wastes

- D001 Ignitable Wastes
- D002 Corrosive Wastes
- D003 Reactive Wastes
- D004 to D043 TCLP Wastes

(Toxicity Characteristic Leaching Procedure)

Let's look briefly at what makes a particular waste fall into one of these characteristics that make it a hazardous waste.



What Is An Ignitable Waste?

- It is a liquid and is capable of burning or causing a fire. This material will have a flash point <u>below</u> 140° F.
- It is not a liquid and is capable, under standard temperature and pressure, of causing fire through friction, absorption of moisture, or spontaneous chemical changes.
- It is an ignitable compressed gas.
- It is an oxidizer or explosive

D001 Waste

Examples include acetone, gasoline, organic peroxides, industrial alcohols, chlorates, permanganates.



What Is A Corrosive Waste?

- The material is a liquid or solid and is capable of eroding materials and human tissue.
- These materials have a pH of <u>2 or less or 12.5 or greater</u>
- It is a liquid and corrodes steel at a rate greater than 0.250 inch per year
- Examples: Alkaline cleaners, some chlorides, fluorides, and acids & bases.

D002 Waste





What Is A Reactive Waste?

Waste that is:

- Capable of reacting dangerously with air and water
- When mixed with water could cause an explosion
- Could release poisonous fumes,
- Capable of detonation or explosive reaction at STP
- Forbidden explosives
- Is shock sensitive.

D003 Waste

Examples include peroxides, picric acid, isocynates, cyanides, sulfides, and chlorine.



What Is A Toxic Waste?

- Material is capable of poisoning humans.
- Contains concentrations of arsenic, barium, cadmium, chromium, lead, mercury, selenium, or silver
- Contains a pesticide or other organic toxin cresols, chloroform, benzene, TCE
- Wastes are determined to be "Toxic" if they fail the TCLP Test (a leachate test).

D004-D043 Wastes



Listed Wastes

- F-listed wastes are from non-specific sources
 - Example: halogenated solvents used to degrease equipment; or, discarded chlorophenol formulations
- K-listed wastes are from specific industrial sources
 - Example: K009: Distillation bottoms from the production of acetaldehyde from ethylene
 - Assume BSU generates no K-listed hazardous wastes.
- U-listed wastes are toxic wastes
- P-listed wastes are acutely hazardous wastes



What Is A Listed Waste?

- The F-list (non-specific source wastes). Solvents that have been used in cleaning or degreasing operations. The F-listed wastes are known as wastes from non-specific sources. These include halogenated and non-halogenated chemicals such as methylene chloride, TCA, TCE, MEK, ethyl ether, xylene, acetone, benzene, chlorinated fluorocarbons, and many others used as solvents.
- Possible examples from laboratories or studios (metalworking, sculpture, painting, printing, etc.):
 - Spent solvent wastes (F001 F005).
 - Wastes from electroplating and other metal finishing operations (F006 -F012, and F019)



What Is A Listed Waste?

- P- and U-listed wastes: These two lists designate certain commercial chemical products as hazardous when spilled or disposed. These unused chemicals may become wastes in a number of ways. Some can be spilled while in use, others are intentionally discarded if out of specification, others are just unused "orphan" or expired chemicals.
- They must meet all three of the following criteria: (1) The formulation must contain at least one chemical on the P or U list; (2) The chemical in the waste must be unused; and (3) the chemical in the waste must be in the form of a commercial chemical product (CCP), which is a chemical that is of technical (commercial) grade, 100% pure, and the only active ingredient in the formulation.
- Hundreds of chemicals are included on both the P- and U-lists. (contact the EHS Office for guidance on these waste identifications).



Examples of P-Listed Wastes

Allyl alcohol	Osmium tetroxide
Ammonium vanadate	Phenylthiourea
Arsenic acid	Potassium cyanide
Arsenic trioxide	Sodium azide
Carbon disulfide	Sodium cyanide
2,4-Dinitrophenol	Thiosemicarbazide
Fluorine	Vanadium oxide
Nitric oxide	Vanadium pentoxide

P-listed chemicals (acutely hazardous wastes) are fairly common in BSU labs – but should be avoided whenever possible. Generating over 1 kg of a "P" waste in a single month is a problem.

27



Examples of U-ListedWastes


Acetaldehyde	1,4-Dioxane
Acetone	Ethyl acetate
Acetonitrile	Ethyl ether
Aniline	Formaldehyde
Benzene	Methyl alcohol
Bromoform	Methylene chloride
1-Butanol	Phenol
Chloroform	Toluene

U-listed (toxic) chemicals are commonly found in BSU labs. Again, though, just because a P or U listed constituent is present in a given chemical does not mean that compound or solution is a hazardous waste when disposed or spilled – it must be the original 100% or sole active ingredient of the product or material.




Caution: Mixing Wastes

- 1. If you mix a hazardous waste with a nonhazardous waste-you may be making the entire mixture a hazardous waste.
- 2. If you mix a <u>listed</u> hazardous waste with a nonhazardous waste (or a characteristic hazardous waste) you may be making the entire mixture a <u>listed</u> hazardous waste.





Hazardous Waste Determination Process





The good news...

- Ball State University recently elected to be covered by Subpart K of the hazardous waste regulation a new alternative RCRA regulation designed specifically for academic laboratories.
- The BSU Hazmat "team" will now decide whether your waste is a RCRA-regulated hazardous waste, a non-regulated hazardous waste, a non-hazardous waste, or a non-regulated waste.
- So, even though you may no longer need to make the final waste type determination-you still needed to know the basic hazardous waste criteria we just covered so that you can relate the necessary information.



Ball State Hazardous Waste Lab (and Studio) Management

- You also need to know to handle potentially hazardous wastes properly – proper containers and labeling, not to mix with other wastes, etc.
- It is this approach (Subpart K) that is described in the following slides for the identification and handling of hazardous wastes from labs and studios.
- Subpart K is not available to industry and does not apply to our shops, maintenance, or custodial wastes only those wastes generated in a laboratory!



Rationale for the Academic Labs Rule (Subpart K)

- Teaching and research labs differ from industry in the following ways:
 - Hazardous waste generation pattern is different
 - Hundreds of different hazardous wastes that vary over time
 - Small amounts of each hazardous waste
 - Many individuals generating hazardous waste in many labs (i.e., many points of generation)
 - Individuals generating the hazardous waste are often students, who
 - Have inherently high turnover (thus difficult to train)
 - Lack the expertise or interest mandated in industry



Lab Wastes



The provisions of Subpart K are intended to bring about safer management of hazardous waste in academic laboratories by:

- Requiring hazardous waste determinations to be made by "trained professionals", rather than students, faculty, or researchers.
- Requiring hazardous waste to be removed from the laboratory every six months (or when a container is full).
- Allowing eligible academic entities the flexibility to decide when and where on-site hazardous waste determinations are made.
- Offering incentives for removing old and expired chemicals that may pose risks from the laboratories.
- Requiring a Laboratory Waste Management Plan to be developed. That plan has been developed is available on the BSU EHS Website.



Lab Wastes

Lab Wastes Can be Either:

- Non-hazardous Wastes;or,
- Hazardous Wastes

This determination will be made later by a "trained professional" based on the completed waste label.

LAB WASTE			
Accumulation Start Date:			
Dept:Bldg/Rm:			
Contact:Phone:			
Waste Name:			
Chemical Composition: %			
Hazard properties (check any applicable):			
☐ Poison ☐ Heavy Metal: ppm			
☐ Flammable ☐ Oxidizer			
☐ Corrosive: pH? ☐ Shock-sensitive			
☐ Reactive to: ☐ Air ☐ Water			
☐ Cyanides: ppm ☐ Sulfides: ppm			
☐ Carcinogen ☐ Irritant ☐ Sensitizer			
☐ Solvents ☐ Chlorinated solvents			
☐ Toxic ☐ Peroxide former			
☐ Biohazard ☐ Non-Hazardous?			
Other:			
Wastes must be removed within 6 months			
of Start of Accumulation in the Container!!			
Contact EHS Office (tlrussell@bsu.edu, or			
5-2807) with questions or for pickup.			




Lab Wastes: Label Contents

All containers of Lab Waste ("unwanted materials") must be labeled with:

Affixed or Attached to the Container:

- 1. The words "Lab Waste"; and,
- 2. Information to alert emergency responders to the contents of the container (e.g., name or list of chemicals or hazard classes)



<u>All</u> waste containers must also have the following information either directly on the container, or associated with the container label:

Associated With Container Label – May be Affixed or Attached if Desired:

- Information sufficient to make a Hazardous Waste determination;
 and,
- 4. Accumulation start date (of the waste in the container)





Lab Wastes: the Container Label

Identifies container as *Unwanted Material* –

BSU term: *LAB WASTE*

Needed to make a HW determination and alerts emergency responders to container contents

Completing the BSU Lab
Waste form meets all of
the EPA container label
requirements

LAB WASTE	
Accumulation Start Date:	
Dept:Bldg/Rm:	
Contact: Phone:	
Waste Name:	
Chemical Composition: %)
Hazard properties (check any applicable)	
Poison Heavy Metal: ppm	10
☐ Flammable ☐ Oxidizer	1
☐ Corrosive: pH? ☐ Shock-sensitive	
Reactive to: Air Water	
Cyanides: ppm	pm
☐ Carcinogen ☐ Irritant ☐ Sensitizer	
☐ Solvents ☐ Chlorinated solvents	
☐ Toxic ☐ Peroxide former	
☐ Biohazard ☐ Non-Hazardous?	
Other:	_
Wastes must be removed within 6 mont	
of Start of Accumulation in the Containe	<u>er!!</u>
Contact EHS Office (tlrussell@bsu.edu, or	


5-2807) with questions or for pickup.

States Start of Accumulation

Date

Alerts emergency responders to the container contents

Alerts emergency responders to container contents and assists in making a HW determination



Lab Wastes: Example

- 1. Start Date date when waste is first added to container (if combining containers the earliest date prevails);
- 2. Contact person who generated or knows the waste?
- 3. Give common waste name;
- 4. Provide contents and estimated percentage; and,
- 5. Check known/likely hazards.

M	
LAB WASTE	
Accumulation Start Date: 9-12-13	
Dept: <u>CHEM</u> Bldg/Rm: <u>CP441</u>	
Contact: C. Cardinal Phone: 5-1241	
Waste Name: <u>Spent Solvent/Cleaner</u>	
Chemical Composition:	6
Acetone 3	<u>o</u>
Methanol 2	<u>:5</u>
Acetic Acid 1	0
Water 3	3 <u>5</u>
	_
	_
Hazard properties (check any applicable	
Poison Heavy Metal: ppr	n
✓ Flammable □ Oxidizer	
✓ Corrosive: pH? <u>3.8</u> ☐ Shock-sensitive	9
☐ Reactive to: ☐ Air ☐ Water	
☐ Cyanides: ppm ☐ Sulfides: p	opm
☐ Carcinogen ☐ Irritant ☐ Sensitizer	
✓ Solvents ☐ Chlorinated solvents	
✓ Toxic ☐ Peroxide former	
☐ Biohazard ☐ Non-Hazardous?	
Other:	
Wastes must be removed within 6 mon	<u>ths</u>
of Start of Accumulation in the Contain	<u>er!!</u>
Contact EHS Office (<u>tlrussell@bsu.edu</u> , or	
5-2807) with questions or for pickup.	



Lab Wastes - Referenced

LAB WASTE	
Accumulation Start Date: 9-12-1.	3
Dept: CHEM Bldg/Rm: CP441	
Contact: C. Cardinal Phone: 5-124:	<u>1</u>
Waste Name: Container #103	
Chemical Composition:	%
Chlorinated Solvents	100_
	:
Hazard properties (check any applicat	30
☐ Poison ☐ Heavy Metal: p	pm
☐ Flammable ☐ Oxidizer	
☐ Corrosive: pH? ☐ Shock-sensit	ive
☐ Reactive to: ☐ Air ☐ Water	
☐ Cyanides: ppm ☐ Sulfides:	
☐ Carcinogen ☐ Irritant ☐ Sensitizer	
☐ Solvents ✓ Chlorinated solvents	;
✓ Toxic ☐ Peroxide former	
☐ Biohazard ☐ Non-Hazardous?	
Other:	
Wastes must be removed within 6 m	
of Start of Accumulation in the Conta	<u>ıiner!!</u>
Contact EHS Office (<u>tlrussell@bsu.edu</u> , or 5-2807) with questions or for pickup.	




Must still have at least LAB WASTE identity and hazard information for emergency responders on the container itself – start of accumulation date and HazWaste information may be "associated" or "referenced"



Lab Wastes: Original Container







Accumulation Start Date: 9-5-13

Dept: Sculpture Bldg/Rm: AJ 102

Contact: Charlie C. Phone: 5-1241

Waste Name: **Unused Linseed Oil**

Wastes must be removed within 6 months of Start of Accumulation in the Container!!

Contact EHS Office (<u>tlrussell@bsu.edu</u>, or 5-2807) with questions or for pickup.

Here you can cut off part of the LAB WASTE label if you like –still need to show that and the Accumulation Start Date, etc. The material hazards (flammability, etc.) and contents should already be on the original container label.



Poison: A waste that either exhibits **Toxic** hazards as defined below, or is otherwise designated a **Poison** based on shipping labels on the constituent containers, on Safety Data Sheets, or container labels related to the contents of the waste container.

Heavy Metal: This refers to the 8 RCRA metals – Arsenic (As), Barium (Ba), Cadmium (Cd), Chromium (Cr), Mercury (Hg), Lead (Pb), and Selenium (Se), and Silver (Ag). If present in the waste in appreciable amounts, name the metal and its approximate concentration.

Flammable: Liquids having a flashpoint of less than 140°F. For solids-may cause a fire through friction; show a burning rate faster than 2.2 mm (0.087 inches) per second; or any metal powders that can be ignited and react over the whole length of a sample in 10 minutes or less. Naphthalene, matches, aluminum powder, and magnesium are examples of flammable solids.

Contact:	Bldg/Rm:
	Phone:
Waste Name:	
Chemical Com	nposition: %
N N	
	
W_A	
00. Vi 10.	
32 02 20	
Hazard propo	rties (check any applicable):
	☐ Heavy Metal: ppm
Flammable	A STATE OF THE PARTY OF THE PAR
	H? Shock-sensitive
	Air Water
	ppm Sulfides: ppm
HE COMPANY TO SHOW THE PARTY OF	☐ Irritant ☐ Sensitizer
	☐ Chlorinated solvents
	☐ Peroxide former
	□ Non-Hazardous?
Other:	
	be removed within 6 months



Oxidizer: Any compound that spontaneously evolves oxygen at room temperature or under slight heating. The term includes such chemicals as chlorates, perchlorates, nitrates, and permanganates. Peroxide-formers should be checked separately where indicated.

Corrosives: Acids and bases or mixtures having a pH less than or equal to 2 or greater than or equal to 12.5, and materials that burn the skin or dissolve metals. Examples are strong mineral acids (chromic, sulfuric, hydrochloric, or nitric) strong alkalis (potassium hydroxide, sodium hydroxide), rust removers, and acid or alkaline cleaning fluids. Specify the pH of the waste where indicated if known or a potential hazard. The presence of perchloric or hydrofluoric acid should also be noted in the Waste Name or Other category.

	LAB WASTE Start Date:
	Bldg/Rm:
	Phone:
Chemical Com	position: %
	
-	
300 N N	
Hazard proper	ties (check any applicable):
	☐ Heavy Metal: ppm
☐ Flammable	Service and the service of the servi
	H? Shock-sensitive
	□ Air □ Water
	ppm
With the man and the same of the same	☐ Irritant ☐ Sensitizer
	☐ Chlorinated solvents
	☐ Peroxide former
	□ Non-Hazardous?
Other:	
	be removed within 6 months
	cumulation in the Container!!



Reactivity: A waste material, other than an explosive, which will vigorously polymerize, decompose, condense, or become self-reactive and undergo other violent chemical changes, including explosion, when exposed to heat, friction or shock, or in the absence of an inhibitor, or in the presence of contaminants or in contact with incompatible material. Check if the material is air or water reactive. Also, check and provide the concentration of any **cyanides** or **sulfides** in the waste. a waste is hazardous if it is a cyanide- or sulfide-bearing waste which generates toxic gases or vapors at a quantity sufficient to present a health or physical danger.

Carcinogen: Any substance or agent capable of causing or producing cancer in mammals, including humans. A chemical is considered to be a carcinogen if it has been listed as such by the International Agency for Research on Cancer (IARC), by the National Toxicology Program (NTP) (latest edition), or if it is regulated by OSHA as a carcinogen.

Dept:			- 12
Contact:			
Waste Name:			
Chemical Com	position	i:	%
		_	
	- 17		
Hazard prope	rties (ch	eck anv a	pplicable):
Poison			
☐ Flammable			
☐ Corrosive: p	H?	☐ Shock	-sensitive
☐ Reactive to:	□Air	☐ Water	
☐ Cyanides:	_ ppm	☐ Sulfide	es: ppn
☐ Carcinogen	☐ Irrita	nt 🗆 Sei	nsitizer
☐ Solvents	☐ Chlo	rinated so	olvents
☐ Toxic	☐ Pero	xide form	er
☐ Biohazard	□ Non-	Hazardou	is?
Other:			
	L	aund with	in 6 months



Irritant: A chemical/material that causes a reversible inflammatory effect on living tissue, and may cause soreness, redness or discomfort.

Sensitizer: A chemical that causes a substantial proportion of exposed people or animals to develop an allergic reaction in normal tissue after repeated exposure to the chemical.

Solvents: Identify if the waste contains materials that were used as a solvent or extraction fluid – either halogenated (methylene chloride, chloroform, trichloroethylene, dichloroethylene, Tetrachloroethylene, 1,1,1-trichloroethane, carbon tetrachloride, chlorinated fluorocarbons, etc.); or non-halogenated (Xylene, acetone, ethyl acetate, ethyl benzene, ethyl ether, methyl isobutyl ketone, n-butyl alcohol, cyclohexanone, and methanol, etc.)

-	M
	LAB WASTE
	Accumulation Start Date:
	Dept:Bldg/Rm:
	Contact:Phone:
	Waste Name:
	Chemical Composition: %
	Hazard properties (check any applicable):
	☐ Poison ☐ Heavy Metal: ppm
	☐ Flammable ☐ Oxidizer
	☐ Corrosive: pH? ☐ Shock-sensitive
	☐ Reactive to: ☐ Air ☐ Water
	☐ Cyanides: ppm ☐ Sulfides: ppm
	☐ Carcinogen ☐ Irritant ☐ Sensitizer
	☐ Solvents ☐ Chlorinated solvents
	☐ Toxic ☐ Peroxide former
	☐ Biohazard ☐ Non-Hazardous?
	Other:
	Wastes must be removed within 6 months
	of Start of Accumulation in the Container!!
	Contact EHS Office (tlrussell@bsu.edu, or
L	5-2807) with questions or for pickup.



Toxic: A waste having the capacity to cause death, illness, or diminished function. A material that meets one or more of the following criteria should be considered toxic:

- Has a published LD₅₀ equal to or less than 0.5 g/kg of body weight.
- Has a published LC_{50} equal to or less than 1000 ppm.
- Has an OSHA permissible exposure limit (PEL) or ACGIH Threshold Limit Value (TLV) equal to or less than 5000 ppm.
- Has an OSHA PEL or ACGIH TLV equal to or less than 10 mg/m³.

Peroxide Formers: Organic peroxides are very unstable carbon-based chemicals that contain the characteristic peroxide (-O-O-) bond. Peroxides can be formed when commonly used laboratory chemicals with the potential to form peroxides react with air, moisture, or impurities. Organic peroxides are extremely sensitive to shock, sparks, heat, friction, impact, and light. These include acrylonitrile, butadiene, cyclohexene,, ethylene glycol diethyl ether, furan, isopropyl ether, methyl isobutyl ketone, vinyl acetate, vinyl chloride, and vinyl ethers.

Dept:	Start Date: Bldg/Rm:	
Contact:	Phone:	- 1
Waste Name:		
Chemical Con	position:	%
- N		-
371		
Hazard prope	rties (check any applicab	le):
	☐ Heavy Metal: p	
☐ Flammable		
☐ Corrosive: p	H? 🗆 Shock-sensiti	ve
	☐ Air ☐ Water	
☐ Cyanides:	ppm Sulfides:	ppm
☐ Carcinogen	☐ Irritant ☐ Sensitizer	
☐ Solvents	☐ Chlorinated solvents	
☐ Toxic	☐ Peroxide former	
☐ Biohazard	☐ Non-Hazardous?	
Other:		
14/	be removed within 6 mg	nthe



Biohazard: An agent of biological origin (e.g., all infectious organisms, their toxins, allergens of biological origin, and genetic fragments) that has the capacity to cause ill-effects in humans.

Explosive: The term "explosive" or "explosives" includes any chemical compound or mechanical mixture which, when subjected to heat, impact, friction, shock, detonation or other suitable initiation, undergoes a very rapid chemical change with the evolution of large volumes of highly heated gases which exert pressures in the surrounding medium. The term applies to materials that either detonate or deflagrate. Explosive wastes do not appear as a label hazard as such materials should be immediately brought to the attention of the BSU EHS Office for proper handling.

Other: Can include any other hazard not listed.

Dept:	Bldg/Rm:	
	Phone:	
Waste Name:		
Chemical Com	position: %	6
		_
		-
- V		
521 N N		_
Usesud susua	rties (check any applicable)	
	Heavy Metal: ppr	
□ Flammable		11
	H? Shock-sensitive	
	☐ Air ☐ Water	
	ppm	nm
	☐ Irritant ☐ Sensitizer	Pin
0	☐ Chlorinated solvents	
	☐ Peroxide former	
	□ Non-Hazardous?	
Other:		
	be removed within 6 mon	the
10 Sec. 10	cumulation in the Contain	_
	fice (tlrussell@bsu.edu, or	



Non-Hazardous: Many chemicals and compounds would not constitute hazardous wastes, only a very few examples include neutralized caustics (pH between 5 and 10), collagen, cytosine, nutrients, starches, cellulase, many biologicals and media, salines, potassium thiosulfate, plasmin, calcium citrate, pectrin, and many others. If a trained individual, based on knowledge of the waste contents and characteristics can determine that the waste is not a RCRA Hazardous Waste, this class may be checked. Normally, this determination will be made following removal of the waste by the Chemical Hygiene Officer or field chemists employed by BSU's waste vendor personnel. However, if you are sure the waste is innocuous it may be checked as Non-Hazardous here-or separately disposed as solid waste or to the sewer as described in the BSU Waste Management Guide.

Dept.	Start Date:Bldg/Rm:
Contact:	Phone:
Waste Name:	
Chemical Con	nposition: %
	
	W 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
Hazard prope	rties (check any applicable):
□ Poison	☐ Heavy Metal: ppm
☐ Poison ☐ Flammable	
☐ Flammable	
☐ Flammable ☐ Corrosive: p	☐ Oxidizer
☐ Flammable ☐ Corrosive: p ☐ Reactive to:	☐ Oxidizer oH? ☐ Shock-sensitive
☐ Flammable ☐ Corrosive: p ☐ Reactive to: ☐ Cyanides: _	Oxidizer OH? Shock-sensitive Air Water
☐ Flammable ☐ Corrosive: p ☐ Reactive to: ☐ Cyanides: _ ☐ Carcinogen	□ Oxidizer pH? □ Shock-sensitive □ □ Air □ Water ppm □ Sulfides: ppm
☐ Flammable ☐ Corrosive: p ☐ Reactive to: ☐ Cyanides: _ ☐ Carcinogen ☐ Solvents	Oxidizer OH? Shock-sensitive OH: Water OH:
☐ Flammable ☐ Corrosive: p ☐ Reactive to: ☐ Cyanides: _ ☐ Carcinogen ☐ Solvents ☐ Toxic	Oxidizer H? Shock-sensitive Air Water ppm Sulfides: ppm Irritant Sensitizer Chlorinated solvents
☐ Flammable ☐ Corrosive: p ☐ Reactive to: ☐ Cyanides: _ ☐ Carcinogen ☐ Solvents ☐ Toxic	Oxidizer H? Shock-sensitive Shock-sensitive Shock-sensitive Shock-sensitive Sulfides: ppm Irritant Sensitizer Chlorinated solvents Peroxide former Non-Hazardous?



Lab Wastes: Handling

- 1. Label properly!
- 2. Use compatible containers in good condition;
- 3. Do not exceed 55 gallons (220 lbs) of waste in particular lab (1 qt. of P-lists);
- 4. Do not exceed 6 months beyond the start of accumulation date;
- 5. All personnel and students in labs must have this basic training;
- 6. Only fully "trained persons" may remove the wastes or make hazardous waste determinations
- 7. EHS has ten (10) days to remove the wastes after container is full or 6 months.



Environmental Health and Safety Office North Service Building

Contact: Tom Russell, CHMN 765-285-2807 <u>tlrussell@bsu.edu</u>

Chemical Waste / Lab Waste Management in Laboratories and Art Studios/Workshops

This checklist is for managing Lab Wastes (Chemical Wastes) in science education and research laboratories, and art studios and workshops, on the main campus of Ball State University. Other

generators of chemical wastes (maintenance shops, housing, dining, etc.) must follow the general chemical and hazardous waste handling procedures for waste generators under U.S.EPA/IDEM hazardous waste regulations.
☐ Determine that the material is unwanted and is not going to be reused at any time.
☐ Determine the container the Lab Waste will be stored in – contact the EHS with questions or if acceptable containers are needed:
 This container must be in good condition and compatible with the waste. Large volumes of waste should be stored in U.S. DOT approved Hazardous Material shipping containers.
☐ Apply a BSU <i>Lab Waste</i> label (yellow) to the container at the time of first filling and complete the label fully and accurately:
 Ensure a descriptive chemical name is printed on the label (no acronyms). Ensure location and contact name is printed on the label.
 Ensure the accumulation start date is printed on the label.
 Ensure the waste components and hazards are recorded on the label.
 Use secondary containment (trays or cabinets) to segregate containers according t hazard class and compatibility.
☐ Ensure each container is closed at all times (except when adding Lab Wastes). See working container and inline system policies for more information.
☐ Ensure you do not exceed 1 kg. (2.2 lbs) of any of the following acutely hazardous materials: Aluminum phosphide, Ammonium picrate, Mercury fulminate, Nitroglycerein, Tetranitromethane, or Zinc phosphide >10%.
☐ Ensure that you do not exceed the smaller of 55-gallons or 220 lbs of Lab Waste.
☐ Ensure that any Lab Wastes are removed by EHS within 6 months of the <i>start of accumulation date</i> on any container – contact the EHS for pickup.
$\hfill \square$ Ensure that all personnel and students who manage Lab Wastes have training.
☐ Ensure all personnel and students working in the Lab Waste generation and storag areas know emergency and spill procedures:
 Post emergency/spill/injury procedures near the lab/studio door.
 Ensure everyone working in the area is familiar with the location and operation of emergency eye washes, showers, fire extinguishers, spill control equipment
☐ Contact the EHS Office to request removal of any Lab Waste containers that are

Environmental Health and Safety Office, Ball State University, North Service Building, 3401 North Tillotson Avenue, Muncie, Indiana 47306, http://cms.bsu.edu/about/administrativeoffices/facilities/ehs

nearly full or upon approaching 6 months of storage, whichever comes first.

The ground, or by evaporation.

□ Do not dilute or dispose of Lab Wastes via drain/sewer, in trash, dumping on



Lab Wastes: Handling

- 8. Be sure all waste containers are always kept closed; EXCEPT:
- When adding, removing, or bulking Lab Wastes; or,
- A Working Container may be open until the end of the procedure or work shift (must then be closed); or,
- When venting of a container is necessary;
- For the proper operation of lab equipment – in-line collection of waste from HPLC; or,
- To prevent dangerous situations, such as build-up of pressure; and,
- Must be 2 gallon or less capacity.



Environmental Health and Safety Office North Service Building

Contact: Tom Russell, CHMM 765-285-2807 ftrussell@bsu.edu

Chemical Waste / Lab Waste Management in Laboratories and Art Studios/Workshops

This checklist is for managing *Lab Wastes* (Chemical Wastes) in science education and research laboratories, and art studios and workshops, on the main campus of Ball State University. Other generators of chemical wastes (maintenance shops, housing, dining, etc.) must follow the general chemical and hazardous waste handling procedures for waste generators under U.S.EPA/IDEM hazardous waste regulations.

☐ Determine that the material is unwanted and is not going to be reused at any time.
☐ Determine the container the Lab Waste will be stored in – contact the EHS with questions or if acceptable containers are needed:
 This container must be in good condition and compatible with the waste. Large volumes of waste should be stored in U.S. DOT approved Hazardous Material shipping containers.
☐ Apply a BSU <i>Lab Waste</i> label (yellow) to the container at the time of first filling and complete the label fully and accurately:
 Ensure a descriptive chemical name is printed on the label (no acronyms). Ensure location and contact name is printed on the label. Ensure the accumulation start date is printed on the label.
 Ensure the waste components and hazards are recorded on the label.
 Use secondary containment (trays or cabinets) to segregate containers according to hazard class and compatibility.
☐ Ensure each container is closed at all times (except when adding Lab Wastes). See working container and inline system policies for more information.
☐ Ensure you do not exceed 1 kg. (2.2 lbs) of any of the following acutely hazardous materials: Aluminum phosphide, Ammonium picrate, Mercury fulminate, Nitroglycerein, Tetranitromethane, or Zinc phosphide >10%.
\square Ensure that you do not exceed the smaller of 55-gallons or 220 lbs of Lab Waste.
☐ Ensure that any Lab Wastes are removed by EHS within 6 months of the <i>start of accumulation date</i> on any container – contact the EHS for pickup.
\square Ensure that all personnel and students who manage Lab Wastes have training.
 Ensure all personnel and students working in the Lab Waste generation and storage areas know emergency and spill procedures: Post emergency/spill/injury procedures near the lab/studio door.
 Ensure everyone working in the area is familiar with the location and operation of emergency eye washes, showers, fire extinguishers, spill control equipment.
☐ Contact the EHS Office to request removal of any Lab Waste containers that are nearly full or upon approaching 6 months of storage, whichever comes first.
☐ Do not dilute or dispose of Lab Wastes via drain/sewer, in trash, dumping on The ground, or by evaporation.

Environmental Health and Safety Office, Ball State University, North Service Building, 3401 North Tillotson Avenue, Muncie, Indiana 47306, http://cms.bsu.edu/about/administrativeoffices/facilities/ehs



Lab Wastes: "P" Wastes

P- Listed Materials

Now, under Subpart K, there are only six (6) acutely hazardous (P-listed) wastes limited to < 1 quart.

Acutely hazardous waste (P-listed material) must be removed from lab within 6 months or when a <u>1-quart limit</u> is reached.

The 6 are:

- 1. P006 Aluminum Phosphide
- 2. P009 Ammonium Picrate
- 3. P065 Mercury Fulminate
- 4. P081 Nitroglycerin
- 5. P112 Tetranitromethane
- 6. P122 Zinc Phosphide > 10%




Lab Wastes: Lab Cleanouts



Laboratory Cleanouts

- Control your inventory- Reduce where possible;
- Subpart K allows a particular laboratory a "once per year" Laboratory Cleanout;
- Best to keep chemicals in their original manufacturer containers;
- Only allowed one per rolling 12-month period;
- EH&S has 30 days (rather than 10 days) from the time the cleanout begins to remove the chemicals from the laboratory;
- The laboratory department can perform the cleanout-or schedule it for EHS and our waste vendor to perform





Lab Wastes: Lab Cleanouts



Laboratory Cleanouts Documentation

- Identify the lab/room being cleaned out;
- An inventory of the chemicals must be provided;
- The date(s) the laboratory clean-out begins and ends;
- The total volume of hazardous waste generated;
- Records must be kept for at least 3 years.
- If done properly, the increased waste volume will not affect our hazardous waste generator status.



Lab Wastes: Responsibilities

Remember:

It is the responsibility of the student, laboratory worker, instructor, Principal Investigator, or manager within the laboratory, studio, or workshop to prepare the label(s) completely and verify that labels are placed on all containers of lab wastes stored in the laboratory, or associated storage or preparation room. In order for the container to be removed from a laboratory or studio it must be identified with the required information.

Hazard properties (check any applicable): Poison	Debt. Dide/Rill.	H
Waste Name:		
Hazard properties (check any applicable): Poison	Waste Name:	at S
Hazard properties (check any applicable): Poison	Chemical Composition:	
Hazard properties (check any applicable): Poison		
Hazard properties (check any applicable): Poison		
Hazard properties (check any applicable): Poison		_
Hazard properties (check any applicable): Poison		
Hazard properties (check any applicable): Poison		
Poison		
Poison		
☐ Flammable ☐ Oxidizer ☐ Corrosive: pH? ☐ Shock-sensitive ☐ Reactive to: ☐ Air ☐ Water ☐ Cyanides: ppm ☐ Sulfides: ppm ☐ Carcinogen ☐ Irritant ☐ Sensitizer ☐ Solvents ☐ Chlorinated solvents ☐ Toxic ☐ Peroxide former ☐ Biohazard ☐ Non-Hazardous? ☐ Other:		
Corrosive: pH? Shock-sensitive Reactive to: Air Water Cyanides: ppm Sulfides: ppm Carcinogen Irritant Sensitizer Solvents Chlorinated solvents Toxic Peroxide former Biohazard Non-Hazardous?		_ ppm
Reactive to: Air Water Cyanides: ppm Sulfides: ppm Carcinogen Irritant Sensitizer Solvents Chlorinated solvents Toxic Peroxide former Biohazard Non-Hazardous?		
☐ Cyanides:ppm ☐ Sulfides:ppm ☐ Carcinogen ☐ Irritant ☐ Sensitizer ☐ Solvents ☐ Chlorinated solvents ☐ Toxic ☐ Peroxide former ☐ Biohazard ☐ Non-Hazardous? Other:	☐ Flammable ☐ Oxidizer	***
☐ Carcinogen ☐ Irritant ☐ Sensitizer☐ Solvents ☐ Chlorinated solvents☐ Toxic ☐ Peroxide former☐ Biohazard ☐ Non-Hazardous?☐ Other:	☐ Flammable ☐ Oxidizer ☐ Corrosive: pH? ☐ Shock-sens	sitive
☐ Solvents ☐ Chlorinated solvents ☐ Toxic ☐ Peroxide former ☐ Biohazard ☐ Non-Hazardous? ☐ Other: ☐ Divide the solvents ☐ Divide th	☐ Flammable ☐ Oxidizer ☐ Corrosive: pH? ☐ Shock-sens ☐ Reactive to: ☐ Air ☐ Water	
☐ Toxic ☐ Peroxide former☐ Biohazard ☐ Non-Hazardous?☐ Other:	□ Flammable □ Oxidizer □ Corrosive: pH? □ □ Shock-sens □ Reactive to: □ Air □ Water □ Cyanides: ppm □ Sulfides:	ppm
☐ Biohazard ☐ Non-Hazardous? Other:	☐ Flammable ☐ Oxidizer ☐ Corrosive: pH? ☐ Shock-sens ☐ Reactive to: ☐ Air ☐ Water ☐ Cyanides: ppm ☐ Sulfides: ☐ Carcinogen ☐ Irritant ☐ Sensitiz	ppm er
Other:	☐ Flammable ☐ Oxidizer ☐ Corrosive: pH? ☐ Shock-sens ☐ Reactive to: ☐ Air ☐ Water ☐ Cyanides: ppm ☐ Sulfides: ☐ Carcinogen ☐ Irritant ☐ Sensitiz ☐ Solvents ☐ Chlorinated solven	ppm er
	☐ Flammable ☐ Oxidizer ☐ Corrosive: pH? ☐ Shock-sens ☐ Reactive to: ☐ Air ☐ Water ☐ Cyanides: ppm ☐ Sulfides: ☐ Carcinogen ☐ Irritant ☐ Sensitiz ☐ Solvents ☐ Chlorinated solven ☐ Toxic ☐ Peroxide former	ppm er
Wastes must be removed within 6 months	☐ Flammable ☐ Oxidizer ☐ Corrosive: pH? ☐ Shock-sens ☐ Reactive to: ☐ Air ☐ Water ☐ Cyanides: ppm ☐ Sulfides: ☐ Carcinogen ☐ Irritant ☐ Sensitiz	ppm er



Lab Waste Pick-Ups

The EHS Office schedules quarterly waste pickups across the campus on the following academic calendar schedule:

Mid-August (after the 2nd Summer Session-before Fall Term)

December (during Winter Break)
March (during Spring Break)
May (after Spring term-before 1st Summer Session)

However, BSU maintains Central Accumulation Area for the temporary storage and staging of Lab Wastes between the quarterly scheduled pickups for off-site treatment and disposal.

Call the BSU EHS Office for pickup of waste of any type whenever necessary – 5-2807 or tlrussell@bsu.edu







Questions?

Contact:

Tom Russell, CHMM, REHS
Environmental Specialist/Chemical Hygiene Officer
Environmental Health and Safety Office
Ball State University
North Service Building
3401 North Tillotson Avenue
Muncie IN 47306
765-285-2807 or tlrussell@bsu.edu



And/or visit the Ball State University EHS Website to review related waste handling information